



THANK YOU FOR YOUR PURCHASE!

The Rhino Coffee Gear Hand Grinder is perfect for grinding coffee 'on the go' for home, work and while travelling

For more tips and tricks, go to rhinocoffeegear.com

AeroPress is a registered trademark of Aerobie, Inc. Palo Alto, CA, USA

1 Remove the Rhino Coffee Gear Hand Grinder and parts from the box.



2 Measure the desired amount of beans and pour into the grinding chamber.



3 Replace lid securely on grinding chamber.



4 Adjust the grind by turning the adjustment knob clockwise for finer and anti-clockwise for coarser.



5 Secure handle to the locating nut and begin grinding.
Note: Make sure handle is kept level when grinding.



USING THE AEROPRESS® ADAPTOR

(RWSHGA only)

Remove bottom chamber and replace with the Aeropress adaptor and attach to AeroPress®.



Start grinding.




CLEANING YOUR HAND GRINDER

Unscrew the adjustment knob, remove the internal and external burrs with care.



HAND GRINDER INSTRUCTION MANUAL



RWHANDGRINDER
Hand Grinder

RWSHGA
Compact Hand Grinder